

## TECHNICAL INFORMATION

### Replacement Ink Rollers

Catalog Nos. PIP100R, PM283PIPR, FRR200, FRR300, FRR400

#### INSTRUCTIONS

*How-To Illustrations are provided on the reverse side and apply to the following models: PIP100H, PM283PIPH, PIP100, PM283PIP, FEL100, FPT262, FPT262A, and FPT262B.*

1. Use disposable gloves to handle replacement ink roller.
2. Remove old roller by loosening the acorn nut/washer(s) from the roller mandrel.
3. Insert the mandrel into the axle hole of the replacement roller and slip over the axle for horizontal rollers. For all other models, slide the axle through one end of the handle bracket and slip a washer over it. Then slip the replacement roller assembly over the axle.
4. Slip washer over the end of the axle and reattach the acorn nut finger-tight. Gently wipe new roller with towelette to remove any excess ink prior to use.

Order# PIP100R	Order# PM283PIPR	
 <p>PIP100H</p> <p>PIP100</p>	 <p>PM283PIP</p> <p>PM283PIPH</p>	
Order# FRR400	Order# FRR300	
 <p>FEL100</p> <p>FPT262B</p>	 <p>FPT262A</p> <th>Order# FRR200</th> <p>FPT262</p>	Order# FRR200

100 HUNTER PLACE, YOUNGSVILLE, NC 27596 USA  
(919) 554-2244, (800) 356-7311 • [www.sirchie.com](http://www.sirchie.com) • [sirchieinfo@sirchie.com](mailto:sirchieinfo@sirchie.com)

**CAUTION:** Consult the appropriate Material Safety Data Sheets (MSDS) found on our website at [www.sirchie.com/support](http://www.sirchie.com/support). Do not clean the roller with a solvent-based cleaner as permanent damage may result. Do not use these rollers with standard fingerprint ink as permanent damage will result.

