

---

## TECHNICAL INFORMATION

### SIRCHPOD® Adjustable Light Support System

Catalog Nos. KSS9200U, KSS9200UL

---

#### INTRODUCTION

The KSS9200 SIRCHPOD® has proven to be a valuable tool in photo applications. Designed primarily for use with the KRIMESITE™ Imager, it facilitates close-up evidence examination and photography. However, separate light sources were necessary. The Adjustable Light Support System satisfies this need. It can be easily attached to the KSS9200 without the use of tools.

With the addition of the Adjustable Light Support System, your SIRCHPOD® becomes a complete, self-contained photo lighting system. The KSS9200UL includes two CUV100TS UV Mini Light Sources (254nm) where the KSS9200U comes without lights. Whether you require shortwave, longwave or standard white fluorescent light, this system can provide



*No. KSS9200UL Components*

just the right light for any of your applications. See the installation instructions that follow to upgrade your KSS9200 with the flexible accessory light support system.

## INSTALLATION

### KSS9200UL

The KSS9200UL upgrade can be easily attached to the KSS9200 without tools.

1. Remove the two front telescoping legs from your SIRCHPOD® by unscrewing them.
2. Slip the KSS9200UL supports directly onto the body of the KSS9200 aligning the corresponding holes.
3. Securely attach into place by screwing in the telescoping legs.



*Unscrew and remove the two front telescoping legs from the KSS9200 SIRCHPOD® body.*



*Slip the KSS9200UL supports directly onto the SIRCHPOD® body. Secure into place by reattaching the legs.*

### KSS9200U

The KSS9200U Accessory Light Support System does not include CUV100TS lights. To use the lights from your old BTS100 unit, you will need to remove them from the rigid support arms.

1. Remove the threaded knobs holding each light onto the rigid support arms.
2. Unscrew the wing nuts securing the lights to the support rods and remove the lights.



*Remove the threaded knobs holding the lights to the rigid support arms.*



*Unscrew the wing nuts securing the lights to the support rods and remove.*



*Install the lights on the BTS100U supports by snapping them into each light cradle.*



**KSS9200 SIRCHPOD®** shown with KSS9200UL attached in use with KSS60 Imager (KSS60 and KSS9200 sold separately).

3. Install the lights on the KSS9200U supports by snapping them into each light cradle.
4. Attach the flexible arms to the KSS9200 as described above for the KSS9200UL.

With either Accessory Light Support System/Upgrade, your SIRCHPOD® (shown to the left) becomes a flexible, fully adjustable lighting system for your KRIMESITE™ Imager.

