



PTV100/S

SIRCHIE®'s innovative line of all unitized fiberglass prisoner transport vehicles were introduced in 1979. To date, the unique design of the molded fiberglass interior continues to provide features and benefits unsurpassed in any other prisoner transport system. The PTV100/S features a sealed interior that can be flushed/cleaned with a standard garden hose for ease of maintenance.



2015 Ford Transit Chasis Shown



Optional Divider with Individually Locking Rear Doors



Optional 3rd Compartment



Available on GM Chasis



Available Video Monitoring System



Custom Built Switch Console

Illustrations and descriptions are subject to change—some equipment shown is optional

PTV100 FEATURES:

- Maximum Utilization of Interior Space: Walls and ceiling contour to van interior providing more space, unlike slide-in box units.
- Unmatched Durability: The fiberglass interior flexes and does not dent like metal fabricated units.
- Thermally Stable: Fiberglass does not retain heat and/or cold to the same extremes as metal.
- Unparalleled Officer Safety: Fully sealed interior prevents transfer of airborne pathogens to cab area. Inner security doors control prisoner unloading.
- Prisoner confinement area available with heating and air conditioning.
- Extreme climate control AC system is optionally available for locations where required.
- Standard units supplied with single prisoner compartment & one rear security door.
- Center divider option provides two compartments and includes two, high security, inner locking doors. Allows for controlled loading and off-loading.
- Third compartment option can be ordered to further segregate prisoners.
- Easy load rear step provides convenient egress of shackled prisoners.
- Emergency escape hatch in cab allows for secondary egress.

PTV900LP Series

Also available providing increased seating in a low height, high payload Ford Cutaway chassis/body design.



About GSA...

A GSA Contract price is pre-negotiated with the Federal government. Under the Co-Operative Purchase Program, these vehicles can be purchased by any State, County, or Municipal agency at the same pre-negotiated price eliminating the bid process. Contact Sirchie at 800-545-7375 or vehicles@sirchie.com.